

Esparragos para bridas ASA

Tubo	8"				10"				12"			
	esp rragos				esp rragos				esp rragos			
SERIE	un	largos		un	largos		un	largos		un	largos	
		RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G
400	12	1"	6 3/4	6 1/2	16	1 1/8	7 1/2	7 1/4	16	1 1/4	8"	7 3/4
600	12	1 1/8	7 3/4	7 1/2	16	1 1/4	8 1/2	8 1/4	20	1 1/4	8 3/4	8 1/2
900	12	1 3/8	8 3/4	8 1/2	16	1 3/8	9 1/4	9"	20	1 3/8	10"	9 3/4
1500	12	1 5/8	11 1/2	11 1/4	12	1 7/8	13 1/4	13"	16	2"	14 3/4	14 1/2

Tubo	20"				24"				26"			
	esp rragos				esp rragos				esp rragos			
SERIE	un	largos		un	largos		un	largos		un	largos	
		RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G
400	24	1 1/2	9 3/4	9 1/2	24	1 3/4	10 3/4	10 1/2	28	1 3/4	12"	
600	24	1 5/8	11 1/2	11 1/4	20	1 7/8	13"	12 3/4	28	1 7/8	14 1/4	
900	20	2"	13 1/2	13 1/2	20	2 1/2	17 1/4	17"	20	2 3/4	18 3/4	
1500	16	3"	21"	21 1/2	16	3 1/2	24 1/2	24"				

	14"				16"				18"			
	esp rragos				esp rragos				esp rragos			
un	largos		un	largos		un	largos		un	largos		
	RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G	
20	1 1/4	8 1/4	8"	20	1 3/8	8 3/4	8 1/2	24	1 3/8	9"	8 3/4	
20	1 3/8	9 1/4	9"	20	1 1/2	10"	9 3/4	20	1 5/8	10 3/4	10 1/2	
20	1 1/2	10 3/4	10 1/2	20	1 5/8	11 1/2	11"	20	1 7/8	12 3/4	12 1/2	
16	2 1/4	16"	15 3/4	16	2 1/2	17 1/2	17 1/4	16	2 3/4	19 1/2	19"	

	28"				30"				32"			
	esp rragos				esp rragos				esp rragos			
un	largos		un	largos		un	largos		un	largos		
	RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G		RF	M&F-T&G	
28	1 7/8	13"	28	2"	13 3/4	28	2"	14"	28	2"	14"	
28	2"	14 1/4	28	2"	15 3/4	28	2"	16 1/4	28	2"	16 1/4	
20	3"	18 3/4	20	3"	20 1/2	20	3 1/4	21 3/4	20	3 1/4	21 3/4	

*Fuente de información ANSI B-16-5, B-16-36, MSS SP 44, BS 3293. RF: (Raised-face) = Cara con resalto. RJ: (Ring Join) = Para junta de anillo. M&F: (Male and female) = Macho y hembra. T&G: (Tongue and groove) = con lengüeta y acanalada.

Esparragos para bridas ASA

Tubo	1/2				3/4				1"				1 1/4			
	esp rragos				esp rragos				esp rragos				esp rragos			
SERIE	un		largos		un		largos		un		largos		un		largos	
			RF	RJ			RF	RJ			RF	RJ			RF	RJ
150	4	1/2	2 1/2		4	01-Feb	2 1/2		4	01-Feb	2 3/4	3 1/4	4	1/2	2 3/4	3 1/4
300	4	1/2	2 3/4	3"	4	05-Ago	3"	3 1/2	4	05-Ago	3 1/4	3 3/4	4	05-Ago	3 1/4	3 3/4

Tubo	3 1/2				4"				5"				6"			
	esp rragos				esp rragos				esp rragos				esp rragos			
SERIE	un		largos		un		largos		un		largos		un		largos	
			RF	RJ			RF	RJ			RF	RJ			RF	RJ
150	8	05-Ago	3 3/4	4 1/4	8	05-Ago	3 3/4	4 1/4	8	03-Abr	4"	4 1/2	8	03-Abr	4"	4 1/2
300	8	03-Abr	4 1/2	5 1/4	8	03-Abr	4 1/2	4 1/4	8	03-Abr	4 3/4	5 1/2	12	03-Abr	5"	5 3/4

Tubo	16"				18"				20"				24"			
	esp rragos				esp rragos				esp rragos				esp rragos			
SERIE	un		largos		un		largos		un		largos		un		largos	
			RF	RJ			RF	RJ			RF	RJ			RF	RJ
150	16	1"	5 1/2	6"	16	1 1/8	6"	6 1/2	20	1 1/8	6 1/4	6 3/4	20	1 1/4	7"	7 1/2
300	20	1 1/4	7 1/2	8 1/4	24	1 1/4	7 3/4	8 1/2	24	1 1/4	8 1/4	9"	24	1 1/2	9 1/4	10 1/4

	1 1/2				2"				2 1/2				3"			
	esp rragos				esp rragos				esp rragos				esp rragos			
	un		largos		un		largos		un		largos		un		largos	
			RF	RJ			RF	RJ			RF	RJ			RF	RJ
	4	01-Feb	3"	3 1/2	4	05-Ago	3 1/4	3 3/4	4	05-Ago	3 1/2	4"	4	05-Ago	3 3/4	4 1/4
	4	03-Abr	3 3/4	4 1/4	8	05-Ago	3 1/2	4 1/4	8	03-Abr	4"	4 3/4	8	03-Abr	4 1/4	5"

	8"				10"				12"				14"			
	esp rragos				esp rragos				esp rragos				esp rragos			
	un		largos		un		largos		un		largos		un		largos	
			RF	RJ			RF	RJ			RF	RJ			RF	RJ
	8	03-Abr	4 1/4	4 3/4	12	07-Ago	4 3/4	5 1/4	12	07-Ago	4 3/4	5 1/4	12	1"	5 1/4	5 3/4
	12	07-Ago	5 1/2	6 1/4	16	1"	6 1/4	7"	16	1 1/8	6 3/4	7 1/2	20	1 1/8	7"	7 3/4

	26"				28"				30"				32"			
	esp rragos				esp rragos				esp rragos				esp rragos			
	un		largos		un		largos		un		largos		un		largos	
			RF	RJ			RF	RJ			RF	RJ			RF	RJ
	24	1 1/4	8 1/2		28	1 1/4	8 3/4		28	1 1/4	9"		28	1 1/2	10"	
	28	1 5/8	10 1/2	11 1/2	28	1 5/8	11"	11 1/2	28	1 3/4	11 1/2	12 3/4	28	1 7/8	12 1/4	13 1/2

*Fuente de información ANSI B-16-5, B-16-36, MSS SP 44, BS 3293. RF: (Raised-face) = Cara con resalto. RJ: (Ring Join) = Para junta de anillo. M&F: (Male and female) = Macho y hembra. T&G: (Tongue and groove) = con lengüeta y acanalada.



Av. Pavon 1013 (1868) - Avellaneda - Buenos Aires - Argentina
 Telefax: (54-11) 4228-8100 / 3003 ó 4209-9694
www.petrobul.com.ar / info@petrobul.com.ar